



Used for fitting onto machine spindle or in standard SK adapters for holding HSK tools.

Design

Using the adjusting screw on the machine spindle or the SK adapter can be accurately adjusted to concentricity. Precise adjustment in face run-out with adjusting screws on adapter flange.

Includes

Clamping cartridge, cover ring, holding screw, and clamping screw.

Note

On request the adapter flanges can be supplied with a KS clamping cartridge for use with minimal lubrication (MQL).